

# Evaluating Low-Cost Sensors for Measurement of Total Volatile Organic Compounds (TVOC) in a Laboratory Chamber

Shilpi Misra, Sandra Albornoz Martin, Salvatore Milletich, Kirsten Koehler

Department of Environmental Health and Engineering, Johns Hopkins Bloomberg School of Public Health, Baltimore, Maryland




## Background

- Volatile Organic Compounds (VOCs) are only routinely monitored at National Air Toxics Trends stations of which there are only 27 stations in the U.S., (compared to over 1000 for PM<sub>2.5</sub>).<sup>1</sup>
- The Environmental Protection Agency does not have federally enforceable standards to regulate household products.<sup>2</sup>
- The term "total VOC" (TVOC) refers to the total concentration of VOCs in given volume of air.<sup>3</sup>
- Low-cost VOC sensors may provide accessible, real-time monitoring of VOCs in various environments.

## Objectives

- Evaluate the **accuracy and precision** of consumer-grade monitors for different TVOC sensors in a laboratory chamber.
- Determine **sensor response** across certain daily-use products among differing environmental conditions.

## Methods



- ▶ Cost considerations
  - <\$300 for low-cost
  - Accessibility
- ▶ Sensor type considerations
  - Electrochemical
  - Metal oxide semiconductor
  - Photoionization detector
- ▶ Calibration, resolution, and output considerations
  - Detection range
  - Calibration timing and maintenance
  - Data logging
  - Charging capacity or battery

## Ambient air, conditioned with activated carbon

- 1-jet Collison nebulizer with different solutions
- Diluted ethanol and acetone
- Differing flow rates between 0-1 LPM
- Differing temperature and relative humidity conditions



## Laboratory Chamber Set-Up



- 3 metal-oxide sensors (BLATN BR-Smart, BRWISSEN BR-A18, and Purple Air Zen)
- Reference instrument (RAE Systems MiniRAE 3000+)
- Testing with 0.1% acetone, 0.5% ethanol

## Results




Figure 1. BRWISSEN Sensors Agreement with Reference (R<sup>2</sup>: 0.6-0.7)




Figure 2. Purple-Air Sensors Agreement with Reference (R<sup>2</sup>: 0.0-0.1)

## Results




Figure 3. BRSMART Sensors Agreement with Reference (R<sup>2</sup>: 0.7-0.8)

## Conclusions

- Two monitors (BR-Smart and BRWISSEN BR-A18) rely on sensors periodically exposed to fresh air to calibrate a zero-VOC baseline reading.
- PurpleAir's sensor does not indicate when the sensor's internal heater has reached the necessary temperature to read out a value; the values may be inaccurate.

## Next Steps

- Continue testing sensor response with other single gases before moving on to the personal care and housing products (e.g., fragrances, hair spray, lotion, deodorant, all-purpose cleaners, disinfectants)
- Evaluate biases due to relative humidity and temperature

## References

- <sup>1</sup>Air Toxics Ambient Monitoring (2024). In EPA.gov. Retrieved January 8, 2025, from <https://www.epa.gov/amtic/air-toxics-ambient-monitoring>.
- <sup>2</sup>Does EPA regulate volatile organic compounds (VOCs) in household products? (2024). In EPA.gov. Retrieved January 8, 2025, from <https://www.epa.gov/indoor-air-quality-iaq/does-epa-regulate-volatile-organic-compounds-vocs-household-products>
- <sup>3</sup>Jia C, Cao K, Valaulkar R, Fu X, Sorin AB. Variability of Total Volatile Organic Compounds (TVOC) in the Indoor Air of Retail Stores. *Int J Environ Res Public Health*. 2019;16(23):4622. Published 2019 Nov 21. doi:10.3390/ijerph16234622

## Acknowledgments

This work was supported by a grant from the U.S. Centers for Disease Control and Prevention, National Institute for Occupational Safety and Health, to the Johns Hopkins Education and Research Center for Occupational Safety and Health (T42 OH0008428) and a Johns Hopkins University Catalyst Award for Dr. Kirsten Koehler.

For further information, please contact: [smisra10@jhmi.edu](mailto:smisra10@jhmi.edu)